Fitness Wristband User Manual

Model: AT-01

Welcome

Enrich your daily life with the Archon Fitness wristband through jogging, running, and sports. With the ability to share with your friends and interact with games and entertainment. Archon tracks steps taken, distance traveled, calories burned and active moments throughout the day. At night time, archon touch tracks your sleep status and sleep quality.

Archon Buddy motivates you, keeps you moving and energized, and creates healthy fun that keeps you and your family fit.

 Archon buddy creates needed challenges and is a powerful force for everyday fitness.

All Archon fitness wristbands can synchronize wirelessly (Bluetooth 4.0) with your mobile phone running Android (4.3 or above) IOS6.x, 7.x system iPhone 4s or above.

Package includes:

Archon Touch Fitness Wristband 1 pc

Charge Clip 1 pc

Charging Cable 1 pc

User Manual 1 pc

Knowing your Archon Touch

3 Sensors

Sweep (left or right) across 3 sensors

Sweep from right to left

Click

Double Click

Press and Hold for 3 seconds

1.   **Charging**

Attach the charge clip to the back of your Archon Touch. Connect the USB port of charging adapter to the micro USB port of the charge clip. The screen will then display a charging icon and it takes around 2 hours to fully up. Press and hold for 3 seconds while charging and your Archon Touch will show the battery percentage.

Charge Clip

2. **Low Power** `LOW POWER`

When the battery has low power, your Archon Touch will vibrate and the screen will display a low power icon.

3. **Setup with your Mobile**

Mobile device Compatibility

Apple IOS Device: Supports all iPhone 4S or above, iPad 3 or above. Support iOS 6.x, 7.x system

Android Device: Supports Android 4.3 or above with Bluetooth Smart 4.0. Archon runs with mobile phones using standard Bluetooth Smart 4.0 protocol, those mobiles with non-standard Bluetooth protocol will affect pairing and consistency.

4. **Setup Procedure**

4.1 Download Archon App

Download Archon App directly from Archon website, Apple Store or Google Play.

www.archon.com.hk

Apple store   Google Play

4.2 Bluetooth pairing
- Charge your Archon Touch.
- Turn on Bluetooth on your mobile Device.
- Start Archon app on your mobile phone.
- Sign up if you are a new member or log-in with your existing account.
- Go to "Settings", select "Device Synchronization" and "Add Device".
- Select Archon Touch and your Archon Touch will display a Bluetooth icon with a question mark `✳?` .
- Click 👆 to confirm within 10 seconds and initiate Bluetooth pairing.
- If pairing is successful, your Archon touch will show a Bluetooth icon with a tick `✳✓` .
- If you want to use the notification function on the Archon Touch, you need to go to the phone system settings and grant permission to the Archon App to access system notifications on your mobile device.

- If you want to pair your mobile phone with another Archon Touch, you are required to unpair the current one and click on setup to pair a new device.
- Please make sure your mobile phone and Archon Touch is within operating distance.

5. Synchronize Archon Touch data with Archon app

Archon Touch will retain 7 days of records on the device, you are recommended to synchronize at least once a day and keep yourself updated with news from Archon.

- Open your Archon app.

- On the main activity screen, press the sync [icon] icon at the upper right corner of the page and select "Sync with device".

- Your Archon Touch will display a sync icon **SYNC** and start to sync. After synchronization, it will display a time, date and battery status icon **16:38 05/28**

6. Display

6.1 Time, Date and Battery Status **16:38 05/28**

Double click [icon] to turn on the screen of your Archon Touch, and it will show the time, date and battery status.

6.2 Pedometer in steps **102356 STEP**

1st Sweep [icon] will show number of steps walked or run during the day.

6.3 Distance in KM **2456 KM**

2nd Sweep [icon] will show distance walked or run during the day.

6.4 Calories in KCAL **678 KCAL**

3rd Sweep [icon] will show your calories burnt during the day based on general metabolic rate.

6.5 Flip [icon]

4th Sweep [icon] will show a flip icon. If you want to flip the screen, you need to press and hold for

3 seconds [icon] until it shows a confirmation icon ✕ **FLIP** ✓. Click the tick to confirm or the cross to cancel.

6.6 Sleep Mode

Archon Touch monitors your sleep quality while you are asleep. 5th Sweep will show a sleep icon

. Press and hold for 3 seconds until you feel a vibration that will switch your Archon Touch from Sport mode to Sleep mode. You can also use the Archon app to set the "Auto Sleep" time. .

While you are sleeping Archon Touch can identify light sleep, deep sleep and awake cycle and record them. Every day after 6 am Archon Touch can automatically detect if you are awake and switch from Sleep mode back to Sport mode. You can review your sleep status at the Archon App after synchronizing your data to your mobile.

6.7 Notification

You can enable or disable different notification options in the Archon app to best fit your needs:

  In-call notification

 Email Notification

 Daily Schedule Notification

 Social Media Notification

 SMS Notification

 Missed Call Notification

- Open Archon app, find Notification settings and turn on the notification you want to receive.
- Make sure Bluetooth is enabled on your mobile device, and Archon Touch is within operating distance.
- Sync your notification selection with the Archon Touch.
- When your mobile device and Archon Touch are within operating range, you will be able to receive notification that you selected, and your Archon Touch will vibrate to alert you when you receive an email or SMS.
- After switched to sleep mode, all notifications will be turned off.

Below are examples for notifications:

16:38 05/28 → 👆 → @ 9 → 👆 → 📅 9 → 👆 →

💬 9 → 👆 → 16:38 05/28

16:38 05/28 → 👆 → @ 9 → 👆 → 📅 9 → 👆 →

💬 9 → 👆 → 📞 9 → 👆 → 88458458 → 👆 →

Mike → 👆 → 16:38 05/28

16:38 05/28 → 👆 → @ 9 → 👆 → 📅 9 → 👆 →

💬 9 → 👆 → 📞 9 → 👆 → 88458458 OR

Mike → 👆 → ✉ 9 → 👆 → Lucas → 👆 →

Hi Mike, How are you? → 👆 → 16:38 05/28

7. Reminder

EXCERCISE 🏃 MEAL 🍴 REMINDER 📱 SLEEP zᶻᶻ

You can set a Caring Reminder to remind yourself time for sport, Sleep, Events or Dining. press"+"to add new reminder. After selecting a reminding time, press OK to enable sync to the Archon Touch. If your mobile is not connected to your Archon Touch, a pop-up screen will appear to request you to link up with your Archon Touch. Once Synchronized, a reminding time will be saved to the Archon Touch. Archon Touch will vibrate gently and display an input reminder icon to alert you.

8. OTA UPGRADING 🔄

Archon Touch supports OTA upgrades through the Archon App. An upgrading icon will appear on your Archon Touch. If the upgrade is successful, your Archon Touch will restart and display time, date and battery status.

9. Goals Achievement ACHIEVED 🏆

If you reach 10,000 steps daily, Archon Touch will vibrate and display an achievement icon. You can set your own target in the App.

10. Safety and Care

- Do not use the device in extreme temperatures. Please don't expose the device to strong sunlight or heavily humid environments. Suitable temperature for the device and accessories is 0° C - 45°C.
- Keep the Archon Touch away from fire or any objects that may cause damage or scratching.
- Please do not attempt to repair, modify or disassemble the Archon Touch.
- Please clean the strap using water periodically, do not use abrasive cleaners that may damage the strap.
- Please use the charge clip included in the package to charge the Archon Touch.
- The Archon Touch is IP67 water-proof /water spray proof (cannot be used during swimming or diving purposes).
- This device complies with R&TTE Directive 1999/5/EC.

11. Reset

If you have problem with your Archon Touch or it does not function properly, you can try to reset it. When your Archon Touch is charging, insert a small pin into the hole on the charge clip and push to reset.

Hole for reset

12. Specifications

Feature	
Model	AT-01
Color	Black/Blue/Green/Pink/Orange/Purple
Display	OLED
Battery Type	Lithium-ion polymer
Battery Capacity	55 mAH
Battery life for stand-by	10 days
Battery life for working	5-7 days
Water resistant	IP67
Connectivity	Bluetooth smart 4.0 LE
Storage temperature	-20℃ to 60℃
Operation temperature	0℃ to 45℃
Reminder	Support
Charger	Clip-on-charger 5V (micro-USB)

13. Frequent Question and Answer

Q: Why BT connection to the Archon Touch has failed?

A: Please check if your mobile phone and operating system fall within the range of compatibility (see point 3). Bluetooth connection may sometimes fail due to mobile phone BT operation. Please turn off Bluetooth and turn on again. Alternatively, switch the phone on and off again. Retry Bluetooth connection.

14. Warranty

Original purchaser of any Archon Fitness Wristband can obtain a 1 year warranty service from Archon or Distributor starting from the date of purchase. Original purchaser must deliver the faulty product in its original package or packaging with equal degree of protection together with a valid invoice to an address specified by Archon. For details, please refer to the Archon website. www.archon.com.hk

What is not included in Limited Warranty?

- Built-in batteries.
- Aesthetic damage where it does not affect the operation or safety of the product.
- Repair costs that have not been approved.
- Damage or breakdown due to flood, wind or other severe weather conditions.
- Damage or breakdown due to fire or any natural disaster.
- The cost of repairing or replacing a product which fails because anyone neglects, abuses or misuses the product.
- The cost of repairing or replacing a product which has been exposed to insect infestation (or similar phenomenon), human or animal fluid/matter.
- Software or data.
- Cost of Data Recovery.

The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Designed by:
Millennium Pacific Concept Limited
www.archon.com.hk
info@archon.com.hk

Version: AT-01 V02.2